

## Signal To Noise Ratio (SNR)

Signal-To-Noise Ratio indicates how much the signal strength is stronger than the present noise. Signal must be stronger than noise (SNR greater than zero) for data transfer to be possible. If the signal is only barely stronger than noise, you may encounter occasional connection drop-offs.

